DLLA151P2631 Liwei Injector Nozzle Technical Instructions

SKU1: G1Z17LA151P2631



LIWEI NOZZLE



DLLA151P2631 Liwei Injector Nozzle Technical Instructions

Content

1. DLLA151P2631 Liwei Injector Nozzle Introduction	3
1.1. DLLA151P2631 Liwei Injector Nozzle's Basic Information	3
1.2. DLLA151P2631 Liwei Injector Nozzle's Common Written Part Number	3
1.3. DLLA151P2631 Liwei Injector Nozzle's Application Information for Injectors	3
1.4. DLLA151P2631 Liwei Injector Nozzle's Specifications and Dimensions Parameters	
1.5.DLLA151P2631 Liwei Injector Nozzle Quality Control	3
1.6.DLLA151P2631 Liwei Injector Nozzle's Customized Service	4
1.7.DLLA151P2631 Liwei Injector Nozzle's Packing List	4
1.8. DLLA151P2631 Liwei Injector Nozzle's Warranty Instructions	
1.9. DLLA151P2631 Liwei Injector Nozzle's Manufacturer	6
2. DLLA151P2631 Liwei Injector Nozzle Technical Support	6
2.1. DLLA151P2631 Liwei Injector Nozzle's Installation Precautions	
2.2. DLLA151P2631 Liwei Injector Nozzle Inspection	6
2.3. DLLA151P2631 Liwei Injector Nozzle Test Measurement	7
2.4. DLLA151P2631 Liwei Injector Nozzle's installation	7
2.5. DLLA151P2631 Liwei Injector Nozzle Test After Maintenance	7
2.6. DLLA151P2631 Liwei Injector Nozzle List of Tools Used During Measurement and Installation .	9
2.7. DLLA151P2631 Causes of Damage to Liwei Injector Nozzle	9
2.8. DLLA151P2631 Liwei Injector Nozzle Technical Support Obtaining Methods	
3. DLLA151P2631 Liwei Injector Nozzle's Purchase and Delivery	10
3.1. DLLA151P2631 Liwei Injector Nozzle's Purchase Payment Terms	10
3.2. DLLA151P2631 Liwei Injector Nozzle's Main Sales Market	10
3.3. DLLA151P2631 Liwei Injector Nozzle's Declaration Requirements	
3.4. DLLA151P2631 Liwei Injector Nozzle's Shipping Ways	10
3.5. DLLA151P2631 Liwei Injector Nozzle's Lead Time	
3.6. DLLA151P2631 Liwei Injector Nozzle's Logistics Time for Destination Out of China's Areas	10
3.7. DLLA151P2631 Liwei Injector Nozzle's Packing	
4.DLLA151P2631 Liwei Injector Nozzle's Storage Standard	12
4.DLLA151P2631 Liwei Injector Nozzle's Storage Standard	13
5.1. Company Introduction	13
5.2. Contact Information	
6. Copyright Statement	13

DLLA151P2631 Liwei Injector Nozzle Technical Instructions

1. DLLA151P2631 Liwei Injector Nozzle Introduction

Injector nozzle is one of the main working parts of the fuel injector. It is responsible for injecting fuel into the combustion chamber and is a key component to achieve precise injection, oil mist formation.

1.1. DLLA151P2631 Liwei Injector Nozzle's Basic Information

0	Title	China Made New Common Rail Liwei Injector Nozzle DLLA151P2631	Quality
	SKU1	G1Z17LA151P2631	China Made New

1.2. DLLA151P2631 Liwei Injector Nozzle's Common Written Part Number

Injector Nozzle Order Number					Injector	Nozzle Eng	raved Num	ber	
of the	Total	0433172631	Soft.	Soft.	19th	DLLA151F	2631	Cath	

1.3. DLLA151P2631 Liwei Injector Nozzle's Application Information for Injectors

(1) DLLA151P2631 Liwei Injector Nozzle's Application for Injectors' Part Number

Injector Part Number		Injector Series	System Pressure	Re-manufactured Part Number	System Pressure
	John I John	Contraction of the contraction o	logic 1 logic	I I I I I I I I I I I I I I I I I I I	Contract 1

(2) DLLA151P2631 Liwei Injector Nozzle's Car Model Matching Information

	Injector Part Number Car Number		Car Number		OE Number	/		/	
V	Y	1	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	1		1		1	

(3) DLLA151P2631 Liwei Injector Nozzle Part Number Common Writing

0433172631, DLLA151P2631, 0 433 172 631, DLLA 151 P 2631, 0433 172 631, DLLA151 P 2631, 0433172 631, DLLA151P 2631, 0 433 172631, DLLA 151P2631, 0 433172 631, DLLA 151P 2631

1.4. DLLA151P2631 Liwei Injector Nozzle's Specifications and Dimensions Parameters

Liwei Injector Nozzle Size: 6 cm*1.5cm *1.5 cm

Liwei Injector Nozzle Tube Dimensions: 7 cm *2 cm *2 cm

Liwei Injector Nozzle Net Weight: 0.03kg Liwei Injector Nozzle Box: 10 cm *8 cm *4cm Liwei Injector Nozzle Gross Weight (10 PCS): 0.3kg Liwei Injector Nozzle Quality: China Made New

Liwei Injector Nozzle MOQ: 10 PCS

1.5.DLLA151P2631 Liwei Injector Nozzle Quality Control

(1) Liwei Injector Nozzle Testing

All parts of the Liwei Injector Nozzle are subjected to precision testing, high temperature testing, low temperature testing, withstand pressure testing, leakage testing, durability testing, and various working conditions testing.

(2) Liwei Injector Nozzle Inspection

The factory inspection of the Liwei Injector Nozzle is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same Liwei Injector Nozzle for a total of no less than three times for factory inspection, and the fuel injector installation testing environment are progressed in dust-free workshop.

(3) Liwei Injector Nozzle Installation

When matching the valve cap and valve steam, Shumatt strictly complies with the standard of valve cap and valve stem clearance technical indicators to ensure that each nozzle meets the factory standards and use standards.

1.6.DLLA151P2631 Liwei Injector Nozzle's Customized Service

(1) Liwei Injector Nozzle's Customized Service: Meet the customized needs of OEM manufacturers for shell lettering, logo engraving, injector nozzle's tube, injector nozzle's box and label customized, etc.



(2) Liwei Injector Nozzle's Customized Service Requirements:

The purchased of Customized injector nozzle's shell lettering or without lettering are no less than 100 pieces. The purchased of Customized injector nozzle tubes are no less than 2000-3000 pieces.

The purchased of customized injector nozzle boxes are no less than 1000 pieces.

Customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

• Once the customized injector nozzle is sold, it cannot be returned or exchanged if there is no quality problems.

1.7.DLLA151P2631 Liwei Injector Nozzle's Packing List

(1) Liwei Injector Nozzle's Spare Parts List

No da	Name Walt	Liwei Injector Nozzle Assy	Notice .	Liwei Injector Nozzle	Tube North
	\(\frac{1}{2}\)				
Noth's	all Koth		. West		*
Hote	Image		ally hot	LA128P21	S
100			10		, E
	rig. rig.	130, 130, 130,	1		
Joine	No.	Str. 1 Str. Str.	Join E	Cont 2	othe



Description	Liwei Injector Nozzle Part Number DLLA151P2631	Prevent nozzle being rusted and damaging from collision
No.	3	
Image (a)	Common Rail Injector Nozzle ISO 9001:2008 Centified © CPIC-Accept Insurance	
Name	10Pcs Liwei Fuel Injection Co., Ltd. www.liwel.com.cn Liwei Injector Nozzle Box	
Description	10 PCS/Box	A State of S

▲ Minors are prohibited to use Liwei injector nozzle, nozzle packing box to avoid getting injury.

▲ Liwei injector nozzle box is recyclable and can be reused。

▲ Liwei injector nozzle tube is non-degradable material, please dispose of it properly after use.

1.8. DLLA151P2631 Liwei Injector Nozzle's Warranty Instructions

(1) Liwei Injector Nozzle's Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the injector nozzle inspection equipment when the nozzle is abnormal during use as evidence to feed back to the salesman.

Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. oil leakage etc.

(2) Liwei Injector Nozzle's Warranty Coverage

Within 15 days after customer receives DLLA151P2631 Liwei injector nozzle if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the DLLA151P2631 Liwei injector nozzle has performance problems during the warranty period (6-12 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the injector house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

(3) Liwei Injector Nozzle Out of Warranty Coverage

Website: www.liweinozzle.com

The warranty period has expired.

Injector nozzle failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.

Injector nozzle damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).

Injector nozzle failure or injector damage caused by non-injector design, technology, manufacturing, quality and other issues.

Injector nozzle failure due to system pressure exceeding system approved pressure.

© 2022 Shenzhen Shumatt Technology Co., Ltd



Injector nozzle failure caused by system voltage exceeding approved voltage.

Injector nozzle failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.

Injector nozzle failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).

Injector nozzle failure caused by not following the installation angle specified in the injector maintenance manual.

Injector nozzle failure caused by not following the cleaning requirements specified in the injector maintenance maintenance manual.

Injector nozzle failure caused by failure to replace consumable parts as specified in the injector maintenance manual.

1.9. DLLA151P2631 Liwei Injector Nozzle's Manufacturer

Injector nozzle's manufacturer: Shenzhen Shumatt Technology Co., Ltd

2. DLLA151P2631 Liwei Injector Nozzle Technical Support

2.1. DLLA151P2631 Liwei Injector Nozzle's Installation Precautions

- (1) Clean the injector nozzle in an ultrasonic cleaner for 3-5 minutes before installation, so as to make the stains, dust, rust-proof oil oxides, paraffin base, naphthenic base, intermediate base, salt, lead naphthenate, zinc naphthenate, sodium petroleum sulfonate, barium petroleum sulfonate, calcium petroleum sulfonate, tallow diamine trioleate, rosinamine on the surface of the nozzle fall off.
- (2) Use compressed air to clean the cleaning fluid attached to the surface of the nozzle after cleaning, and clean it up to the standard of use, as below.

2.2. DLLA151P2631 Liwei Injector Nozzle Inspection.

Website: www.liweinozzle.com

(1) Check whether there is deformation, cracking, thread damage, quenching, leakage and rust in the guide sleeve, spring, gasket and tight cap of the nozzle. The tight cap of the nozzle must be replaced after being disassembled for more than 5 times, as shown in the following.



- (2) Replace the tight cap of the nozzle and the copper gasket of the Liwei Injector Nozzle
 - (3) Check whether the gap between the nozzle needle and the nozzle shell is within the standard range



and whether it reaches the standard for use

All parts should be examined for wear under a microscope at least 20 times larger

A Nozzle tight cap deformation, cracking, thread damage, quenching, leakage, will lead to black smoke vehicle cap, fuel injector damage.

lacklacklacklacklacklack Injector opening pressure greater than or less than the specified range may cause injector damage.

Failure to replace wearing parts in time during maintenance may lead to fuel injector damage.

2.3. DLLA151P2631 Liwei Injector Nozzle Test Measurement

(1) Nozzle opening pressure test

Test whether the opening pressure range of the nozzle is within the range specified in the injector maintenance manual (to be verified), if not within the normal range, adjust the nozzle spring to adjust the gasket

If the value is greater than normal, reduce the oil nozzle spring adjusting gasket; if the value is less than normal, increase the oil nozzle spring adjusting gasket.

(2) Stroke Measurement of Nozzle Needle Valve

Use a measuring tool to measure whether the stroke of the nozzle needle valve is within the range (15-45um) specified in the injector maintenance manual. If not, adjust the stroke of the nozzle to adjust the gasket.



If the value is greater than normal, thicken the gasket for oil-nozzle needle valve lift adjustment; if the value is less than normal, reduce the gasket for oil-nozzle needle valve lift adjustment

2.4. DLLA151P2631 Liwei Injector Nozzle's installation

(1) Tightening torque of injector nozzle

The torque lever and tightening moment specified in the injector maintenance manual must be installed when the injector nozzle is installed. (50Nm)



The tightening torque of the nozzle cap must be installed in accordance with the tightening torque specified in the injector maintenance manual

2.5. DLLA151P2631 Liwei Injector Nozzle Test After Maintenance

(1) After installation, it needs to be tested on the test bench.







The correct injector type should be selected for testing

(2) The test results need to be ensured that the following items are within the standard data range of the test stand.

LEAK TEST: Test whether sealing test is up to standard or not

In this step, no injector collector should be installed at the nozzle during the test so as to observe whether the nozzle is dripping oil, meanwhile observe that all joints are no oil leaking.

The static oil return of the test should not exceed 8mm2/H, otherwise, you need to check whether the high-pressure sealing ring, valve assembly, and stroke parameters of the injector are within the standard range.

VL: Test whether full load oil (main injection, high speed) is up to standard or not

This step needs to be combined with vehicle driving conditions, such as power, fuel consumption and smoke as well as the maintenance of the engine, if there is situation of insufficient power, fuel consumption is high, thick black smoke and irregularly maintenance of the engine, the engine needs to be maintained according to the maintenance handbook at very first time.

Each of injector part needs to be adjusted and checked if there is any damage according to above situations to ensure the injector is normal. After make sure the injector works normal, you need to reduce the armature stroke if too much oil injection, and increase the armature stroke if too little oil injection.

The error of each injector should be controlled in 6mm3/HH when adjusting.

TL\EM: Test whether the torque point, emission point, exhaust limit, fuel supply reach standard or not Through this test, it is detected that when the oil injection is too little, the engine's acceleration is slow, vice versa, when the oil injection is too much, the engine's acceleration will produce black smoke and the engine excessive exhaust emissions.

Injector nozzle spring force gasket, armature stroke, lift gasket and solenoid valve spring force gasket determine whether exhaust restriction and injector fuel supply reach standard

LL: Test if the idle fuel supply reached the standard

This test detects oil injection is too much will cause engine idle smoke, otherwise if the oil injection too little will cause engine idling easy to stall, or difficult to start.

The uneven of oil injection causes the unstable rotation speed of engine, making noise, and increase the engine swing in the acceleration process.

Each injector error should be controlled within 2mm3/HH when adjusting.

Idle speed fuel supply quantity mainly by adjusting the nozzle spring force gasket.

VE: Test whether the pre-injection meets the standard

Website: www.liweinozzle.com

This test detects when oil injection is too much will cause cylinder knocking while the engine is working and



the exhaust emissions is not up to standard (smoke).

While when oil injection is too little will cause big noise while the engine is working, the engine is difficult to start, the engine weak acceleration, slow response of injector.

Each injector error should be controlled within 0.5mm3/HH when adjusting.

2.6. DLLA151P2631 Liwei Injector Nozzle List of Tools Used During Measurement and Installation

shull	
CRT084	CRT220
Torque wrench: 19-110nm 1/2 used to control tightening force and Angle during installation	Fuel injector stroke measuring tool: used to measure buffer stroke of fuel injector, armature stroke and remaining air gap
	Shundt Calle
	CRT281
Ultrasonic cleaning machine: used for cleaning fuel injector and parts	Common rail injector test equipment: check the injector working condition
shumatt	
Carle o O Carle	Wedt Watt West With
CRT079	Y Y
Micrometer: used to measure gasket thickness	Hote High Hote
	Torque wrench: 19-110nm 1/2 used to control tightening force and Angle during installation Ultrasonic cleaning machine: used for cleaning fuel injector and parts CRT079 Micrometer: used to measure gasket

2.7. DLLA151P2631 Causes of Damage to Liwei Injector Nozzle

Website: www.liweinozzle.com

- (1) Liwei injector nozzle failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in fuel exceeding standard requirements.
- (2) The nozzle is normally worn due to long time working under high temperature
- (3) Nozzle needle wear leads to oil hole blockage, insufficient fuel injection injector can not work properly.
- Nozzle needle wear leads to oil hole blockage, insufficient fuel injection injector can not work properly.

The wear of the nozzle nozzle leads to the increase of fuel quantity, resulting in black smoke of the vehicle, and the fuel injector can not work properly when it is serious.

▲ If the nozzle needle can not move smoothly stuck may cause serious damage to the Liwei injector nozzle.

The rusting of the nozzle spring leads to spring fracture and black smoke from the vehicle.



The opening pressure of the nozzle decreases, and the oil quantity of the injector increases, leading to black smoke of the vehicle, and the injector can't work properly when it is serious.

• Oil-nozzle needle valve lift adjustment gasket wear oil-nozzle needle valve stroke becomes larger, the fuel injector oil quantity becomes larger, resulting in black smoke of vehicles, resulting in the fuel injector can not work properly when serious.

A

The cracking of the nozzle cap is caused by high intensity work under high temperature.

2.8. DLLA151P2631 Liwei Injector Nozzle Technical Support Obtaining Methods

- (1) Liwei Injector Nozzle Technical File , visit http://shumatt.com to get the technical file
- (2) Injector Technical Videos

Facebook: Visit https://www.facebook.com/hison.li constantly follow can get more information.

YouTube: https://www.youtube.com/channel/UCByvYBx7VjV mAfxh Hu-aw to get the technical videos, constantly follow can get more information.

Shumatt: Visit http://shumatt.com to get the technical videos.

(3) Liwei Injector Nozzle Information Query Software

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit http://shumatt.com to get the download and installation tutorial

(4) Search The nozzle test data through TruckBook Parts EPC APP.

3. DLLA151P2631 Liwei Injector Nozzle's Purchase and Delivery.

3.1. DLLA151P2631 Liwei Injector Nozzle's Purchase Payment Terms

Payment Terms: T/T, PayPal, Alipay, WeChat

Please contact our salesmen for specific payment information.

3.2. DLLA151P2631 Liwei Injector Nozzle's Main Sales Market.

Liwei injector nozzle's main sales markets: Asia, Europe, North America, South America, Africa etc.

3.3. DLLA151P2631 Liwei Injector Nozzle's Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

3.4. DLLA151P2631 Liwei Injector Nozzle's Shipping Ways

Destination in China's areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations out of China's areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

3.5. DLLA151P2631 Liwei Injector Nozzle's Lead Time

Lead time: Send out within 3 – 7 working days after receiving payment (Except for special products and special cases).

3.6. DLLA151P2631 Liwei Injector Nozzle's Logistics Time for Destination Out of China's Areas DHL Logistics Time:

9	Country or Region of Departure	Hong Kong, China	Other Countries or Regions of Asia	Australia and New Zealand	Europe	America	Other Countries
	China's Mainland	7 Days	7 Days	8 Days	8 Days	8-12 Days	7-10 Days

UPS Logistics Time: Country or Region of Departure: China's Mainland

Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time
Japan	3 Days	Notice UK Notice	5-7 Days	Egypt	5-7 Days
Turkey	5-7 Days	Singapore	3 Days	Switzerland	5-7 Days



Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days	
Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days	
Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days	7
Malaysia	3-5 Days	Israel (graft)	5-7 Days	Mexico	7-10 Days	7
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days	
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days	7
Lebanon	5-7 Days	Philippine worth	3-5 Days	Greece	7-10 Days	7
South Korea	3 Days	Spain	5-7 Days	Myanmar	5-7 Days	
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days	7
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days	1
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days	7
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days	7
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days	7
Kuwait	7-10 Days					7

▲ The logistics time is for reference only, subjects are according to the actual arrival.

3.7. DLLA151P2631 Liwei Injector Nozzle's Packing

Domestic express packaging: Usually wrapped in waterproof scotch tape, such as picture No.1.

International express packaging: Wrapped with waterproof yellow tape After wrapping the black protective film, such as picture No. 2.

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 3, Also, the products can be packaged according to customers' requirements.


⚠ The packing tray is made of plastic and can be recycled.

A Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.



Domestic express packaging:
Wrapped by Transparent tape



Pic No.2

International express packaging:

Wrapped with yellow tape after wrapping black protective film



Pic No.3

Pallet Shipping: Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties

4.DLLA151P2631 Liwei Injector Nozzle's Storage Standard

(1) Choose a suitable storage place

The warehouse and cargo yard where the fuel injector is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acid, alkali, salt and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

(2) Strict requirements of warehousing

Strict inspections should be carried out when the fuel injectors are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged injectors must be protected from damage.

(3) Keep the warehouse dry and preventing moisture

Website: www.liweinozzle.com

The relative humidity is usually below 70% for the fuel injectors placed in the room, and the corrosion of the fuel injectors is significantly reduced.

Injectors must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

(4) Stack Properly

After the injector is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the injector from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse

If the fuel injector package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

A It is forbidden to leave the injector exposed in the air for a long time.

It is forbidden to store acid, alkali, salt and other substances together with the injector.

The unpacked fuel injector must be rust-proof during secondary storage.



5.Company Information



5.1. Company Introduction

Chinese Name: 深圳市舒马特科技有限公司

English Name: Shenzhen Shumatt Technology Co., Ltd

Mob Phone/WeChat: +86-13410541523

HK Telephone: +852-67653519
Telephone: +86-755-23215133
Email: ruby@shumatt.com
Website: www.shumatt.net

Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway

Station, Bao'an District, Shenzhen, China's Mainland

Shenzhen Office: Room 428-430, Building B, Huafeng Zhigu Technology Industrial Park, Exit B, Fuyong

Metro Station, Bao'an District, Shenzhen, China's Mainland

Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding product

maintenance reasons (Reference: 1.8. DLLA151P2631 Liwei Injector Nozzle's Warranty Instructions)

5.2. Contact Information

Name	WeChat/ WhatsApp	Email		
Ruby	+86-13410541523	hison@shumatt.com		

6. Copyright Statement

Website: www.liweinozzle.com

The copyright of "DLLA151P2631 Liwei Injector Nozzle Technical Instructions" belongs to Shenzhen Shumatt Technology Co., Ltd. And it is authorized to www.liweinozzle.com. Without the written permission of Shenzhen Shumatt Technology Co., Ltd, any users or other third parties are not allowed to modify, spread, re-post, display or mirror "DLLA151P2631 Liwei Injector Nozzle Technical Instructions", otherwise you will bear legal responsibility. Any users or other third parties who have to use the contents of "DLLA151P2631 Liwei Injector Nozzle Technical Instructions" should indicate the source from Shenzhen Shumatt Technology Co., Ltd.



